




ARMLIFT

- User manual



Translation of original user manual
Part no.: 88266-04-en-GB
Producer: EdmoLift AB
Issue date: 2018-10-31

EDMOLIFT ARMLIFT

1	Important information	5
1.1	Technical support	5
1.2	Spare parts and accessories	5
1.3	Recycling	6
1.4	Warranty	6
1.5	Product approval	7
2	Safety regulations	8
2.1	General	8
2.2	Pay attention!	8
2.3	Applications	8
2.4	External safety measures	8
2.5	Product selection	9
2.6	Installation	9
2.7	Prior to use	10
2.8	Operation	10
2.9	Maintenance	16
3	Design and function	17
3.1	General	17
3.2	Scope of delivery	17
3.3	Mechanical construction	18
3.4	Control devices	19
3.5	Hydraulic system	19
3.6	Electrical and control system	22
4	Operation	23
4.1	General	23
4.2	Prior to use	24
4.3	Control	25
4.4	Locking lowering motion	29
4.5	Checking the function of the safety frame	29
5	Maintenance	31
5.1	Hydraulic system	31
5.2	Electrical equipment	32
5.3	Mechanical equipment	32
5.4	Lubrication points	32
6	Installation	33
7	Settings	38
7.1	Safety frame switch	38
7.2	Setting the flow control valve - Lowering speed	39
7.3	Checking the hydraulic system pressure	40
8	Troubleshooting	41

EDMOLIFT ARMLIFT

9	Labels and signs	43
9.1	EdmoLift label	44
9.2	Max. load label	44
9.3	Maintenance label	44
9.4	Warning label	44
9.5	Machine plate	45
9.6	User plate	45
10	Technical data	46
10.1	Specifications	46
10.2	Permitted load distribution	46
10.3	Max. lateral loading	46
11	Wiring diagrams	47
11.1	Identifying applicable wiring diagram	47
11.2	Wiring diagram for UC60 Standard	48
12	Hydraulic diagrams	55
12.1	Single acting hydraulic system, VE14 + VE27	55

1 Important information

Before you start using your EdmoLift product, it is important that you read and understand the content of this user manual in its entirety.

The user manual contains important safety and maintenance information and describes any problems that may occur during use. The user manual is also intended to teach you about the product's functions and properties and how to best use them.

Print the user manual and keep it near to the product, as important information regarding use, safety and maintenance may be required. Information can also be obtained from www.edmolift.com

All information, as well as images, illustrations and specifications are based on the product information that was available at the time of publication of this user manual. Images and illustrations found in the user manual are type examples, they are not intended to be exact depictions of different parts of the product. We retain the right to make changes to the product without prior information.

1.1 Technical support

For support or service, please contact your EdmoLift sales representative. Always state the serial number and machine type as per the machine plate, see section 9.5 *Machine plate*, page 45.

1.2 Spare parts and accessories

Visit www.edmolift.com/installation for more information and then contact your EdmoLift sales representative.

1.2.1 General

Only EdmoLift original spare parts may be used. Use of other parts invalidates the product warranty.

EdmoLift stocks all spare parts for standard products. It may sometimes be appropriate to hold some recommended spare parts in your own stock. We can suggest the appropriate stock for your specific conditions.

1.2.2 Ordering

When ordering spare parts, always state the serial number and machine type as per the machine plate. The machine plate is usually located on the base frame on the operator's side, see section 9.5 *Machine plate*, page 45.

State the part numbers of the spare parts according to the available spare parts information on www.edmolift.com/installation and state the required quantity. Also state the operating voltage regarding electrical components.

1.3 Recycling

This product is manufactured from recyclable materials or materials that can be reused. Specialised companies handle worn out products, dismantle them, and recycle materials that can be reused.



Caution

Spilled or used hydraulic oil must be handled as hazardous waste.



Caution

Electrical material and packaging is handled according to local regulations.

1.4 Warranty

This product is supplied with a warranty in accordance with the applicable agreement, which is stated in the order specification. The warranty covers material and manufacturing faults that may occur during the warranty period during normal use.

The warranty does not cover:

- Normal wear.
- Faults caused by insufficient maintenance.
- Faults caused by incorrect or careless use.

NB!

The seals on electrical equipment may not be broken, if they are, the warranty is deemed invalid.

Warranty repairs must first be approved by EdmoLift AB. Repairs must then be carried out by EdmoLift AB or a contracted partner or in accordance with the agreement made with your EdmoLift sales representative.

1.4.1 Returns

Always contact EdmoLift AB or your EdmoLift sales representative regarding any returns to obtain a return number. The return must be marked with your name, address and telephone number.

NB!

Returns without a return number will be destroyed upon receipt.

Worn, damaged or unusable parts must be returned within 30 days of receipt of the replacement part, if the fault is deemed to fall within the warranty conditions.

1.5 Product approval

This product can be used in a large number of different applications. This means the product is covered by many laws and regulations, issued for the whole EEA area (EU countries as well as Norway, Iceland, Switzerland and Lichtenstein) and those that are national.

This product is constructed according to standard EN 1570–1, lift tables that serve up to 2 fixed stop levels, which is a standard that gives approval to the Machinery Directive, when applied in full.

For this product we usually supply an EC declaration of conformity to the Machinery Directive, a 2A-declaration, based on EN 1570–1.

In some cases, supplements with accessories or composition for an installation are made by a party other than EdmoLift, e.g. a machine installation or lift builder, or by the customer themselves. In such cases, EdmoLift issues a 2B-declaration, Declaration of incorporation of partially completed machine, and then the person or company responsible for completion must issue a 2A Declaration of Conformity.

NB!

This product can be used in applications not covered by the Lift table standard EN 1570–1 without any other standard. Other use, not covered by a standard may also be considered. In such cases, an individual risk assessment and CE marking must be made according to the Machinery Directory.

2 Safety regulations

2.1 General

It is important to read and follow the instructions and safety precautions in this user manual before using the product.

EdmoLift AB is not responsible for any damage to product or property or personal injury, caused by the user or another person not following the recommendations, warnings and instructions contained in this user manual. EdmoLift AB accepts no responsibility for accidents or injuries caused by ill judgement.

2.2 Pay attention!

The user manual contains "warnings", which are intended to draw your attention to conditions that can lead to unwanted problems, incidents, personal injury or damage to the product etc.



Warning

Pay particular attention. Risk of personal injury as well as damage to the product and its surroundings.



Caution

Pay attention.

2.3 Applications



Warning

Use of this product for other applications or loading cases not described in this user manual is not permitted and invalidates the product warranty.

2.4 External safety measures



Warning

In addition to the product's built-in safety details, additional safety measures may be required on or next to the product. Discuss appropriate measures with EdmoLift AB or your EdmoLift sales representative, safety officer, inspector or equivalent. A risk assessment must be undertaken for the work area. Also see section 2.8.6 *Risks during use*, page 13.

2.5 Product selection

Warning

Choosing the right product starts with EdmoLift AB's loading conditions that apply to each application. Inclined loading, point loads or horizontal loads are only permitted within the specified values according to EN 1570-1, unless stated as permitted for the relevant case.

2.6 Installation

Warning

Do not install the product in such a way that amplifies the noise it generates.

Never let the moving parts come into contact with surrounding objects. Ensure that applicable regulations and norms regarding safety distances are met.

Do not install the product in a potentially explosive environment if it is not specially adapted for it.

Ensure that the product is anchored by bolts or equivalent on a secure, flat and horizontal base before use.

The base must have sufficient bearing capacity for the product including a load, as well as a strength class corresponding to concrete C12/15 or greater.

When installing fixed control devices, position the control device so that the operator has a clear view of the product's dangerous areas and load.

Minimise crushing risks when installing next to other equipment and ensure that required safety distances are met according to applicable norms and local regulations.

Check that the product's specified voltage corresponds to the mains voltage, and that a sufficient conducting area and fuse are used.

More than one emergency stop may be required for the product to achieve overall safety at the worksite. In cases where the only operator location is on the platform, at least one additional emergency stop must be installed, easily accessible in connection to the product. Attention must always be drawn to the additional emergency stops by clear labelling.

Warning

The electrical installation must be performed by an authorised electrician and other installation work performed by skilled personnel with the required knowledge in order that the work is carried out in a professional manner. Risk of personal injury.

2.7 Prior to use



Warning

Before each shift, check that the product is in good working order and that all safety devices are intact. Any faults must be rectified before the product is used.

The operator must have a clear view of the armlift and work area during operation. Risk of personal injury.

2.8 Operation

2.8.1 General



Warning

This product should only be used by authorised trained personnel for its intended use. Remember that you, as the user, have responsibility for anyone being injured!

This product must be operated gently, carefully and attentively. This increases safety and reduces maintenance costs and the risk of operational stoppages.

The product must not be overloaded, this can cause a risk of accidents resulting in personal injury and/or property damage.

Do not raise the platform if the space above it is not clear of obstructions.

The platform must not be moving during loading and unloading.

Never insert parts of your body or objects under the platform unless it is in the service position according to section 4.4 *Locking lowering motion*, page 29.

Do not lower the platform if the area beneath it is not clear of people or other obstacles

Do not use the product in connection with welding, unless it is especially adapted for it. The surface finish of the product can produce hazardous gases during welding or grinding. Use suitable protection and work methods.

This product must not come into direct contact with food unless specially adapted.

When used in public environments, especially where people can enter the machine's work area, the operator must take appropriate actions to prevent people entering the risk area. A risk assessment according to the Machinery Directive must be established for the relevant work situation.

There must not be any load on the platform during inspections, servicing and repair work. Inhibit the scissor construction using the maintenance chocks, according to section 4.4 *Locking lowering motion*, page 29.

Do not let any part of your body come into contact with hydraulic oil as it can cause allergic reactions.

2.8.2 Carriage of persons

Warning

In cases where it is permitted to ride on or stay on a raised platform:

Do not climb down from a raised platform!

Never operate the product from the platform before the installation is complete and the necessary safety devices are in place.

Always stand with both feet on the platform and always keep within the platform. Do not sit or climb on handrails or gates!

2.8.3 Protective equipment

Warning

Use protective footwear and other necessary protective equipment required for the work tasks.

2.8.4 Centre of gravity

Warning

Always try to distribute the load evenly on the platform in order to avoid instability. Avoid loads that extend beyond the platform and always make sure that the load is firmly positioned and, if necessary, is also securely fastened.

This product should not be used for handling free-swinging loads.

Under no circumstances must the rated load and centre of gravity distance be exceeded, as this entails a personal injury risk and a damage risk to the product and its surroundings. See section 10.2 *Permitted load distribution*, page 46.

2.8.5 Surroundings



Warning

The standard version of the product is designed for indoor use in environments with normal humidity and temperatures of +5 to +40°C.

When working close to machines there are usually crushing risks. Observe caution, there is a risk of personal injury and property damage!

Never let the moving parts come into contact with surrounding objects. Ensure that applicable regulations and norms regarding safety distances are met.

Do not use the product in a potentially explosive environment if it is not specially adapted for it.

EdmoLift products are not insulated against electrical currents and do not give any protection against contact with live objects and cables.

Always keep a safe distance from live objects and cables.

2.8.6 Risks during use

This section states some risks and examples of measures to prevent them. Certain accessories that increase safety or contribute to increased efficiency can be found in “Examples of measures”.

NB!

The list does not consist of all possible risks and is only intended for use as a guide when establishing an individual risk assessment.

	Risk	Example of measure
General risks	Unauthorised use.	<ul style="list-style-type: none"> • Training. • Instructions. • Clear labelling. • Lockable main switch. • Lockable control device. • Separate the work area.
	Unauthorised entry under raised platform.	<ul style="list-style-type: none"> • Clear labelling. • Protective mesh or protective bellows. • Cordon off the work area.
	Overloading.	<ul style="list-style-type: none"> • Training. • Instructions. • Clear labelling. • Adjust the load.
	Operation error.	<ul style="list-style-type: none"> • Training. • Instructions. • Clear labelling.
	Applicable laws and regulations not met.	<ul style="list-style-type: none"> • Perform a risk assessment. • Check applicable laws and regulations for the installation.
	Diminished performance. Shortened service-life.	<ul style="list-style-type: none"> • Adjust the usage intensity. • More frequent service intervals and inspections.

	Risk	Example of measure
	Risks at the interface around the armlift.	<ul style="list-style-type: none"> • Perform a risk analysis for the installation. Ensure clear view.
	The installation is not CE labelled.	<ul style="list-style-type: none"> • Establish action plan to CE label the installation.
	Crushing risk.	<ul style="list-style-type: none"> • Training. • Instructions. • Clear labelling. • Check that the necessary safety distances are met according to the applicable standards.
	Material can fall off.	<ul style="list-style-type: none"> • Securing devices. • Location of work place. • Prevent access to risk area.
	Instability.	<ul style="list-style-type: none"> • Training. • Instructions. • Clear labelling. • Observe load distribution. • Check attachment. • Note lateral forces and stabilize as necessary.
Surroundings	Extreme ambient temperatures.	<ul style="list-style-type: none"> • Use correct type of oil. • Equip with free-standing hydraulic power pack in adapted space. • Heat/cool the area.
	Fire risk.	<ul style="list-style-type: none"> • Use correct type of oil. • Equip the hydraulic power pack with oil cooler. • Equip with free-standing hydraulic power pack in adapted space.

	Explosion risk.	<ul style="list-style-type: none"> • Equip with EEx equipment according to the ATEX directive. • Equip with free-standing hydraulic power pack in adapted space.
	Environmental impact.	<ul style="list-style-type: none"> • Biodegradable oil. • Oil collection receptacle.
	Foodstuff impact.	<ul style="list-style-type: none"> • Foodstuff approved oil. • Adapt the cleaning agent according to surface treatment.
	Moisture impact.	<ul style="list-style-type: none"> • Control moisture content. • Adapt corrosion protection. • Equip with free-standing hydraulic power pack in adapted space.
	Dust impact.	<ul style="list-style-type: none"> • Control dust content. • Equip with bellows around mechanism. • Equip with free-standing hydraulic power pack in adapted space.

	Weather impact.	<ul style="list-style-type: none"> • Protect from rain. • Adapt corrosion protection. • Equip with free-standing hydraulic power pack in adapted space. • Equip with bellows around mechanism. • Note lateral forces and stabilize as necessary.
Moving mobile Armlifts with or without load.	<p>Collision with persons or other objects.</p> <p>Uneven surfaces cause overturning.</p> <p>Material falls off.</p>	<ul style="list-style-type: none"> • Movement must occur carefully and with a clear view of the surroundings. • Consider the size of the load and position of the platform, whether the load must be secured. • The platform must be in the bottom position when moved.

2.9 Maintenance



Warning

Regular inspection, maintenance and cleaning is important to maintain low maintenance costs, a high level of safety as well as a long service life for the product.



Warning

No load should be on the platform during inspection and service work. Risk of personal injury.

During inspection and service work under the platform, the maintenance chocks must always be positioned in the locked position, see section 4.4 *Locking lowering motion*, page 29. Risk of personal injury.



Caution

Spilled or used hydraulic oil must be handled as hazardous waste.

3 Design and function

3.1 General

EdmoLift Armlift can be used in a large number of different applications. In its primary design, it is mainly intended for lifting, lowering and tilting loads that are distributed across the platform surface, e.g. on Euro pallets, shipping pallets or pallet cages box.

EdmoLift Armlift provides the opportunity to lift and tilt the platform and thus also the load. It provides improved ergonomics, productivity and quality for the tasks performed. However, tilting brings the risk that the load carrier and the load may fall, which can cause damage to persons and equipment that are in the danger area. It is therefore very important:

- To place the Armlift so that people are not in the danger area when tilting occurs.
- to perform tilting in such a way that the load carrier or load cannot fall off
- to use load carriers (pallets, pallet collars, pallet cages, fixtures and similar) that are suitable for the goods being handled.

A common accessory is a load restraint adapted for the current load, which prevents the load sliding off the platform.

EdmoLift Armlift is intended for use on flat and solid surfaces on floors. The base must have sufficient bearing capacity for the armlift, including load. EdmoLift ArmLift should be anchored in the base, to avoid accidental movement during collisions, and to prevent instability.

The relevant product's intended use and load distribution is shown in the "EC declaration of conformity" document.

3.2 Scope of delivery

The standard electrical equipment is intended for connection to 3~ 400VAC, 50Hz. Neutral cable not used. Actual supply voltage is stated on the connection cable and on the electrical equipment.

The control system is 24V DC powered.

In standard form the product is painted in the following colours:

- Blue = RAL 5002
- Orange = RAL 2010
- Black = RAL 9005

3.3 Mechanical construction

EdmoLift Armlift has parallel lifting and tilting arms. The lifting and lowering movements of the arms as well as the tilt movement are synchronized by being mechanically interconnected with each other by crossbars and through the table top and base frame.

Lifting and Tilt force is accomplished by single-acting cylinders. Each cylinder has a built in hose burst valve combination with a double sealed electrical lowering valve that sits directly on, or mounted on a pipe between the cylinders. The electrical lowering valve only opens when the buttons on the control device are pressed and regulate the oil flow correctly. In addition, the hydraulic power pack has a flow control valve, which is set to an appropriate lowering speed, however max. 60 mm/s, on delivery.

NB!

The vertical movement has a lateral movement of up to 440 mm, depending on the lift movement




Image 1 The vertical movement has a lateral movement of up to 440 mm, depending on the lift movement




Image 2 Overview

- | | |
|--------------------|-------------------------|
| 1. Tilt cylinder | 5. Hydraulic power pack |
| 2. Bearing kit | 6. Safety frame switch |
| 3. Hydraulic hose | 7. Lift cylinder |
| 4. Anti-crush rail | |

3.4 Control devices

3.4.1 General

Control device consists of Control buttons for control and an emergency stop button.

1. Emergency stop
2. Up
3. Down
4. Tilt up
5. Tilt down

3.4.2 Emergency stop

There is an emergency stop on the control device. This is red, clearly marked and used in emergencies to stop all electrically powered functions.




Image 3 Control devices

3.4.3 Control buttons

The control device has four control buttons, up, down, tilt up and tilt down. The buttons have a dead man's grip function, i.e. when you release the control button, the platform movement stops in the current position.

3.5 Hydraulic system

EdmoLift armlifts come with either an integrated or external single acting hydraulic system. Due to the product's wide range of use, the hydraulic system is usually adapted individually. The relevant hydraulic and wiring diagrams are enclosed on delivery.

In order for the hydraulic system to work optimally, it is important to use the correct type of hydraulic oil and ensure a high level of cleanliness.

3.5.1 Hydraulic pump

The hydraulic pump supplies the product's hydraulic cylinders with oil, via hoses and/or pipes as well as valves, and powers the hydraulic functions.

3.5.2 Valve package

The hydraulic power pack's valve package controls the flow of the hydraulic oil to the hydraulic cylinders. They are operated by one or more solenoids that receive signals from the product's control system. The valve package contains a pressure-compensated, constant flow valve that can regulate the lowering speed. It must always be set so that the peripheral speed when lowering fully laden does not exceed 60 mm/s. Type of valve varies depending on model and configuration. Certain models have several constant flow valves for controlling the speed of several functions.

1. Solenoid
2. Overflow valve
3. Flow control valve, adjustable
4. Tema 100 output for manometer (Pressure gauge)




Image 4 The valve package is mounted on the hydraulic power pack

3.5.3 Lowering valve - hydraulic lock

EdmoLift ArmLifts are equipped with cylinder mounted, electrically-operated lowering valves.

The electrically-operated valve prevents the platform from being lowered, except when the down button is pressed (3).

The lowering valve reduces hydraulic deflection and provides an anti-drop function, which locks the platform at the relevant level.

There is an LED on the solenoid that lights when the platform is being lowered.

1. Solenoid
2. Hydraulic hose connection
3. Hydraulic cylinder connection




Image 5 Electrically-operated lowering valve

3.5.4 Hydraulic cylinder

EdmoLift armlifts are equipped with one or more hydraulic cylinders that power the different functions. The standard hydraulic cylinders for raising and lowering functions are single acting. The standard hydraulic cylinders for tilt function are single acting.

3.6 Electrical and control system

The UC-60 control system makes it possible to easily program desired functions such as, for example, retrofitting of upper and lower limit position switches for limiting the movement of the platform. Limit position switches and extra control devices are simply connected to the control system.

The main switch and motor protection relay are not included in EdmoLift's delivery, but must be installed by the installer. The feed cable is connected to the main power switch's terminal blocks.

Wiring diagrams for standard products can be found in section 11 *Wiring diagrams*, page 47.

The electrical system is individually adapted, the relevant wiring diagram is then included in the delivery.

To see which electrical diagram applies to your product, see section 11.1 *Identifying applicable wiring diagram*, page 47.

4 Operation

4.1 General

After use, the platform must be lowered to the bottom position and the current switched off at the main power switch.

In the event of risk of unauthorised use, the main power switch can be locked in the off position. The control device can also be locked.



Warning

This product should only be used by authorised trained personnel for its intended use. Remember that you, as the user, have responsibility for anyone being injured!

This product must be operated gently, carefully and attentively. This increases safety and reduces maintenance costs and the risk of operational stoppages.

The product must not be overloaded, this can cause a risk of accidents resulting in personal injury and/or property damage.

Do not raise the platform if the space above it is not clear of obstructions.

The platform must not be moving during loading and unloading.

Never insert parts of your body or objects under the platform unless it is in the service position according to section 4.4 *Locking lowering motion*, page 29.

Do not lower the platform if the area beneath it is not clear of people or other obstacles

Do not use the product in connection with welding, unless it is especially adapted for it. The surface finish of the product can produce hazardous gases during welding or grinding. Use suitable protection and work methods.

This product must not come into direct contact with food unless specially adapted.

When used in public environments, especially where people can enter the machine's work area, the operator must take appropriate actions to prevent people entering the risk area. A risk assessment according to the Machinery Directive must be established for the relevant work situation.

There must not be any load on the platform during inspections, servicing and repair work. Inhibit the scissor construction using the maintenance chocks, according to section 4.4 *Locking lowering motion*, page 29.

Do not let any part of your body come into contact with hydraulic oil as it can cause allergic reactions.

4.2 Prior to use

The function of the safety frame must always be checked before use, see section 4.5 *Checking the function of the safety frame*, page 29. If the safety frame is activated, the cause of the stoppage must be investigated and rectified. Thereafter, the up or down button (depending on which safety protection stopped the function) must first be pressed briefly, so-called resetting, before the tilt table can be used normally again.



Warning

Before each shift, check that the product is in good working order and that all safety devices are intact. Any faults must be rectified before the product is used.

The operator must have a clear view of the armlift and work area during operation. Risk of personal injury.



Warning

Always try to distribute the load evenly on the platform in order to avoid instability. Avoid loads that extend beyond the platform and always make sure that the load is firmly positioned and, if necessary, is also securely fastened.

This product should not be used for handling free-swinging loads.

Under no circumstances must the rated load and centre of gravity distance be exceeded, as this entails a personal injury risk and a damage risk to the product and its surroundings. See section 10.2 *Permitted load distribution*, page 46.

4.3 Control

EdmoLift Armlift should be operated gently, carefully and attentively! The operation functions occur with a dead man's grip function, i.e. when a control button is released the platform stops in its current position. After use, the platform must be lowered to the bottom position and the current switched off at the main power switch. In the event of risk of unauthorised use, the main power switch can be locked in the off position. The control device can also be locked.

Check that there is no risk of injuring anyone or damaging anything when lowering the platform. Pay particular attention so that the platform does not extend over an object, on which it can be suspended.

1. Emergency stop
2. Up
3. Down
4. Tilt up
5. Tilt down




Image 6 Control devices

4.3.1 Emergency stop

4.3.1.1 Activation

Depress the emergency stop to stop all electrical functions.




Image 7 Activation of emergency stops.

4.3.1.2 Resetting

Turn the emergency stop clockwise to reset.



Warning

Emergency stops may only be reset after the cause of the emergency stop has been established and operation can be restarted safely.

NB!

Resetting emergency stop only allows movement to restart, no function is activated automatically at reset of the emergency stop.




Image 8 Resetting emergency stops.

4.3.2 Up

Press and hold up to raise the platform. The movement is stopped as soon as the control button is released.



Image 9 Up

4.3.3 Down

NB!

If the safety frame is activated, the cause of the stoppage must be investigated and rectified. Then, up must be pressed briefly first, before the lowering can be started again.

Press and hold down to lower the platform. The movement is stopped as soon as the control button is released.




Image 10 Down

4.3.4 Tilt down

NB!

If the safety frame is activated, the cause of the stoppage must be investigated and rectified. Then, up must be pressed briefly first, so-called reset, before tilting down can be started again.

Press and hold tilt down for the platform to tilt down. The movement is stopped as soon as the control button is released.




Image 11 Tilt down

4.3.5 Tilt up

Press and hold tilt up for the platform to tilt up. The movement is stopped as soon as the control button is released.




Image 12 Tilt up

4.4 Locking lowering motion

Warning

No load should be on the platform during inspection and service work. Risk of personal injury.

During inspection and service work under the platform, the maintenance chocks must always be in the locked position. Risk of personal injury.

Always cut the operating voltage before starting service work. Risk of personal injury.

4.4.1 Activating maintenance chock

1. Move the platform up to its top position.
2. Place the maintenance chocks in their locked position.

NB!

Locking must always be done on both sides.

3. Carefully lower the platform until it rests on the maintenance chocks.

4.4.2 Deactivating maintenance chock

1. Move the platform up to its top position.
2. Place the maintenance chocks in their locked position.
3. Carefully lower the platform to its lowest position.



Image 13 Maintenance chock.

4.5 Checking the function of the safety frame

Before you start using EdmoLift Armlift, check that Safety frame functions.

1. Operate to a suitable height and ensure that the crushing risk is not present.
2. Lower the platform and activate the safety frame by pressing it up by hand. Repeat the function test on all sides of the platform to ensure the function of the safety frame.




Image 14 Checking the function of the safety frame.

5 Maintenance

The following maintenance must be performed regularly, approx. 4 times/year or at intervals of 1000 lift cycles if this occurs first. Certain types of operating conditions and work environments can require shorter service intervals. Discuss the appropriate service interval with your EdmoLift sales representative.

All inspection, servicing and repair work must be performed by skilled personnel with the required knowledge, in order that the work is carried out in a professional manner. Always replace defective and damaged parts.

Only EdmoLift original spare parts may be used. Use of other parts invalidates the product warranty.

For detailed information about repairs, contact an EdmoLift sales representative.



Warning

Regular inspection, maintenance and cleaning is important to maintain low maintenance costs, a high level of safety as well as a long service life for the product.



Warning

No load should be on the platform during inspection and service work. Risk of personal injury.

During inspection and service work under the platform, the maintenance chocks must always be positioned in the locked position, see section 4.4 *Locking lowering motion*, page 29. Risk of personal injury.



Caution

Spilled or used hydraulic oil must be handled as hazardous waste.

5.1 Hydraulic system

- Check that oil reservoirs, pipes, hoses, couplings and hydraulic cylinders are not damaged or leaking. Rectify any leaks and replace damaged parts.
- Check the fluid level. Top up if necessary.

If the oil is dirty, it must be changed.

EdmoLift Armlift is supplied with standard hydraulic oil according to ISO 32 (see order specification regarding alternatives).

NB!

Maximum volume in the tank is reached when the platform is in the bottom position.

5.2 Electrical equipment

- Ensure that all electrical equipment works as intended.
- Function test all emergency stops, see section 4.3.1 *Emergency stop*, page 26.
- Function test the safety frame, see section 4.5 *Checking the function of the safety frame*, page 29.
- Inspect all cables. Check that they are not loose or pinched. Rectify as required. Replace any damaged cables.

5.3 Mechanical equipment

- Check that pins are properly secured.
- Check that there is no excessive bearing play.
- Check for fractures or bursts.
- Check that the safety frame's profiles and mountings are intact.
- Make sure that the Armlift is firmly anchored in the base.
- Check that all warning signs are present and legible, see section 9 *Labels and signs*, page 43.

5.4 Lubrication points

Bearing points must be relieved at lubrication!
See section 4.4 *Locking lowering motion*.

1. Piston rod bearing




Image 15 Lubrication points

6 Installation

Simplified installation instructions with illustrations accompany the delivery. If missing, they can be downloaded from www.edmolift.com/installation.

NB!

Check the product for transport damage. The electrical cable for connection is under the platform.

Do not lift by the safety frame, it can become damaged resulting in malfunctions. (the platform can be raised but not lowered.)



Image 16 Do not lift by the safety frame.



Warning

Do not install the product in such a way that amplifies the noise it generates.

Never let the moving parts come into contact with surrounding objects. Ensure that applicable regulations and norms regarding safety distances are met.

Do not install the product in a potentially explosive environment if it is not specially adapted for it.

Ensure that the product is anchored by bolts or equivalent on a secure, flat and horizontal base before use.

The base must have sufficient bearing capacity for the product including a load, as well as a strength class corresponding to concrete C12/15 or greater.

When installing fixed control devices, position the control device so that the operator has a clear view of the product's dangerous areas and load.

Minimise crushing risks when installing next to other equipment and ensure that required safety distances are met according to applicable norms and local regulations.

Check that the product's specified voltage corresponds to the mains voltage, and that a sufficient conducting area and fuse are used.

More than one emergency stop may be required for the product to achieve overall safety at the worksite. In cases where the only operator location is on the platform, at least one additional emergency stop must be installed, easily accessible in connection to the product. Attention must always be drawn to the additional emergency stops by clear labelling.



Warning

The electrical installation must be performed by an authorised electrician and other installation work performed by skilled personnel with the required knowledge in order that the work is carried out in a professional manner. Risk of personal injury.

NB!

The seals on electrical equipment may not be broken, if they are, the warranty is deemed invalid.

1. Place the armlift in the desired position. The surface must be level and have sufficient load-bearing capacity.




Image 17 Place the armlift on a level surface with sufficient load-bearing capacity.

2. Place the hydraulic power pack in the desired location.
3. Remove the lid from the hydraulic power pack by pulling it straight up.
4. Remove the transport cover from the hydraulic tank and install the lid that is stored next to it and secured with a cable tie during transport.
5. Pull out the connecting cable through the recess on the side of the hydraulic power pack.
6. Lift out the control device and disconnect it from the hydraulic power pack. Route the cable through the recess on the side of the hydraulic power pack and reinstall the connector to the hydraulic power pack connector marked X0.
7. Insert the hydraulic hose of the armlift and the safety frame sensor cable through the recess on the side of the hydraulic power pack.
8. Connect the hydraulic hose to the constant flow valve.
9. Connect the safety frame sensor cable to the Hydraulic power pack connector marked X6.




Image 18 Installation of external hydraulic power pack

- 10.** Plug in the electrical connection to run the armlift. The feed cable is a 4-core, 3-phase (black, blue, brown) and earth (green-yellow). Neutral cable is not used. CEE connector, motor protection and main power switch are not included in the delivery. Unless otherwise requested, the product is supplied for connection to 3 phase/400 V/50 Hz. (For 380-420V). Actual voltage stated in the order specification.



Image 19 Electrical connection.

- 11.** Connect to power.

- 12.** Press the control device's button to raise the platform. Release the button when the platform is at the required height or after approx. 10 seconds if the platform does not raise. If the platform is not raised, the hydraulic pump is probably rotating in the wrong direction, shift the electrical connection phases (see image 19) and then make a new attempt to raise the platform.




Image 20 Press the control device's button to raise the platform.

- 13.** Block the platform, see section 4.4 *Locking lowering motion*, page 29 .

- 14.** Anchor the Armlift to the base using at least four expander bolts.




Image 21 Anchor the Armlift to the base using at least four expander bolts.

- 15.** Mount the platform load restraint with at least four screws. Install with nuts on the underside of the platform. See image 22.




Image 22 Install the load restraint with at least four screws.

- 16.** Deactivate the platform's chocks, see section 4.4.2 *Deactivating maintenance chock*, page 29.
- 17.** Check that all functions including emergency stop work. The platform Tilt movement shall at no time exceed 0.15 m/s.
- 18.** Check that the anti-crush rail functions, see section 4.5 *Checking the function of the safety frame*, page 29.
- 19.** Check that all labels and signs are intact and in their correct position, see section 9 *Labels and signs*, page 43.

7 Settings

7.1 Safety frame switch

7.1.1 Checks

Ensure that there is a play of 0.5–1.5 mm between the platform and the switch, see image 23.

7.1.2 Setting

The distance between the safety frame and the switch is adjusted by changing the position of the safety frame, see image 23.

1. Place the armlift in the service position, see section 4.4 *Locking lowering motion*, page 29.
2. Adjust the safety frame position by turning the mounting nuts.



Warning

Ensure that all safety frame mountings are equally adjusted, so that the safety frame is parallel with the platform. Risk of personal injury.

3. Check the play according to section 7.1.1.




Image 23 Setting the safety frame.

7.2 Setting the flow control valve - Lowering speed

Use the flow control valve's knob to set the lowering speed.



Warning

High speed increases the risk of instability. The lowering speed may not exceed 60 mm/s.

1. The valve package is mounted on the hydraulic power pack, see image 24.
2. Release the knob by loosening the lock nut.
3. There are different types of valve package depending on the product and its configuration. Identify which type of valve package your product has and which knob belongs to the function to be adjusted. Adjust the speed using the knob. Turn clockwise to reduce the speed. Turn anticlockwise to increase the speed.
4. Lock the knob by tightening the lock nut.




Image 24 The valve package is mounted on the hydraulic power pack. Identify the type of valve package your product has. Adjust the lowering speed using the flow control valve knob.

7.3 Checking the hydraulic system pressure

The valve package is mounted on the hydraulic power pack and is equipped with an output of the Tema 100 type for the connection of a pressure gauge.

NB!

If the product has a limit position, this may have to be removed so that the platform can be operated up to the mechanical stop.

Correct pressure is stated on the machine plate, see section 9 *Labels and signs*, page 43.

1. There are different types of valve package depending on the product and its configuration. Identify which type of hydraulic package your product has, see image 25.
2. Connect suitable pressure gauge to the output, see pos. 4 image 25. The output is equipped with a protective cover that must be removed before connection.
3. Raise the platform to the top position, read off the hydraulic system's pressure on the previously connected pressure gauge when the lift function hits the mechanical stop.
4. Remove the pressure gauge after completing the check.
5. Replace the protective cover on the output.




Image 25 The valve package is mounted on the hydraulic power pack. There are different types of valve package depending on the product and its configuration

- | | |
|--|--|
| 1. Solenoid | 3. Flow control valve for lowering speed |
| 2. Adjustment of max. working pressure | 4. Output for pressure gauge |

8 Troubleshooting

This section contains a troubleshooting guide that describes a number of errors and events that may arise when using your product as well as suggestions for corrective action. Note that this guide does not describe all the problems and events that may arise. If in doubt, you should always contact an EdmoLift representative.

Symptom	Possible cause	Solution
Motor will not start.	Main power switched off.	Switch on the switch.
	No voltage.	Check supply voltage.
	Emergency stop depressed.	Turn emergency stop clockwise. See section 4.3.1.2 <i>Resetting</i> , page 26.
	Blown fuse.	Check cause and reset.
No lifting motion.	Incorrect direction of rotation of motor.	Swap two phases. Warning! Check that the main power switch is off before starting work! See section 6 <i>Installation</i> , page 33.
	Incorrect electrical connection.	Check the connection.
	The pressure relief valve opens.	The platform is overloaded. Remove the excess load.
	Other causes.	Contact EdmoLift.
Maximum lift movement not reached.	Insufficient fluid.	Top up with fluid, not more than the top position. Too much fluid can cause fluid to flow out of the tank during lowering.
	The pressure relief valve opens.	The platform is overloaded. Remove the excess load.
Jerky lift or lowering movement.	Air in the hydraulic system.	Check the fluid level. Run the product 2-3 times at 5 minute intervals. When the platform reaches the bottom position - hold the DOWN button for 30 seconds.

Symptom	Possible cause	Solution
Platform does not lower.	Incorrect electrical connection.	Check the connection.
	Emergency stop depressed.	Turn emergency stop clockwise.
	Safety frame activated.	Remove the object that activated the safety frame. Briefly press up, then down again. See 4.3 <i>Control</i> , page 25.
	Blown fuse.	Check cause and reset.
	Lowering valve does not open.	Check the power supply. Necessary replacement of valve cartridge and solenoid.
The platform lowers without down being pressed.	Dirt in the hydraulic system.	<ol style="list-style-type: none"> 1. Run the product a few times to remove any particles from the valve seats. 2. Remove the lowering valve cartridge and clean. 3. Replace lowering valve cartridge and change fluid.
Lowering speed is faster or lower than desired.	Incorrectly adjusted flow control valve.	Adjust the constant flow valve to max. 60 mm/s. See section 7.2 <i>Setting the flow control valve - Lowering speed</i> , page 39.

9 Labels and signs

Regularly check that the labels and signs on the product on delivery are intact, legible and in the correct language. Damaged or illegible labels must be replaced with new ones.

In special cases, other locations than those shown here may apply. In addition, further labels may be applied in connection with certain accessories or usage situations.

The following signs must be installed:

1. EdmoLift labels, 2 x. See section 9.1.
2. Max. load labels, 2 x. See section 9.2.
3. Machine sign, 1 x. See section 9.5.
4. Maintenance labels, 2 x. See section 9.3.
5. Warning label, 1 x. See section 9.4.




Image 26 Labels and signs

9.1 EdmoLift label

Label with logo and web address.



Image 27 EdmoLift label

9.2 Max. load label

The label indicates the maximum permitted load for the product. The label must be positioned so that it is clearly visible from all operating locations.



Image 28 Max. load label

9.3 Maintenance label

The label indicates that work inspection under the platform is not permitted unless the maintenance chocks are in the maintenance position.



Image 29 Maintenance label

9.4 Warning label

The label provides information about load distribution, permitted or non-permitted carriage of persons, the position of the maintenance chocks and encourages reading of instructions before use and service work.



Label for non-permitted carriage of persons



Label for permitted carriage of persons

Image 30 Warning label

9.5 Machine plate

The machine plate contains the following information:

1. Product type
2. Year of manufacture
3. Hydraulic pressure
4. IP class
5. Serial number
6. Max. load
7. Dead weight




					
TYPE		MAN YEAR		PRESSURE	
<input type="text"/>		<input type="text"/>		<input type="text"/>	
SERIAL NO.		MAX. ED LOAD		DEAD WEIGHT	
<input type="text"/>		<input type="text"/>		<input type="text"/>	
EdmoLift AB				Tel. no +46 (0)611 837 80	
Härnösand, Sweden				b2b@edmolift.se	

Image 31 Machine plate

9.6 User plate

The user plate contains product specifications as well as information about operation and safety. This plate must be sited alongside the operator's operating position, if local regulations so require. User plates are supplied when stated in the order specification.

10 Technical data



10.1 Specifications

For technical specifications, see order specification.



10.2 Permitted load distribution

Max. load stated in the technical specifications regards loads evenly distributed across the entire platform. EdmoLift ArmLifts meet the requirements according to the lift table standard SS-EN 1570-1, where the basic requirement for max. load is defined as follows:


100 % of the max. load distributed across the entire platform.



or 50 % of the max. load distributed across half the platform longitudinally.



or 33 % of the max. load distributed across half the platform laterally.



10.3 Max. lateral loading

Max. permitted lateral force on the platform is 5% of the max. load stated in the technical specifications.

Lateral forces occur, for example, when pressure is applied to the lift or the load by hand tools, or by pulling a tool or machinery part onto the Lift tables platform. If the lateral force is applied to the load, the tipping torque increases, which can cause the load to become unstable or move.

NB!

It is very difficult to estimate the size of the actual lateral force, so utmost care must always be taken.

11 Wiring diagrams

11.1 Identifying applicable wiring diagram

This section shows the wiring diagrams for standard products. The electrical system is individually adapted, the relevant wiring diagram is then included in the delivery but can also be obtained from www.edmolift.com/installation.

To see which electrical diagram applies to your product, see the electrical equipment's label. The correct wiring diagram can be identified using part no. and DIP.





Image 32 Identifying applicable wiring diagram, in the chapter 38000–A0


11.2 Wiring diagram for UC60 Standard

11.2.1 Component layout




Project description UC60-Standard Voltage alternatives	Drawing description Component Layout	Drawn Anders Jonsson Rev. 1	Sign ANDJO	Date 2013-07-01	Sheet size A3	Order 38000	Page 1
						File 38000-1	Of 5


11.2.3 Wiring diagram 3~230VAC




11.2.4 Wiring diagram 3~400-500VAC




11.2.5 Wiring diagram 3~400–500VAC - prepared for automatic device



11.2.6 Integrated hydraulic power pack



11.2.7 Freestanding hydraulic power pack



12 Hydraulic diagrams

12.1 Single acting hydraulic system, VE14 + VE27




Image 33 Single acting hydraulic system, VE14 + VE27 (Part no. 515439)

Index

A

Accessories 5

C

Control 25

Control device 19

E

Electrical and control system 22

Emergency stop 26

F

Flow control valve - Setting..... 39

H

Hydraulic cylinder 21

Hydraulic pump..... 19

Hydraulic system 19

Hydraulic system - Checking pressure 40

I

Important information..... 5

Installation 33, 35

L

Labels..... 43

Lowering speed - Setting 39

Lowering valve 21

Lubrication points 32

M

Maintenance 31

Maintenance chock..... 29

O

Operation 23

P

Product approval..... 7

R

Recycling..... 6

S

Safety frame - Function check..... 29

Safety frame's switch - Setting 38

Safety precautions..... 8

Signs 43

Spare parts..... 5

Specifications 46

T

Technical data 46

Technical support 5

Troubleshooting..... 41

V

Valve package..... 20

W

Warranty..... 6

Wiring diagrams..... 47

About EdmoLift

EdmoLift is one of the worlds largest manufacturers of scissor lift tables, pallet handling products and tools for materials handling. We have successfully supplied lift tables and solutions for materials handling for over 50 years. The largest customer category is industrial companies, but our lift solutions are also available within distribution, healthcare, service and trade.

Our mission is to be the most competitive supplier on the market. EdmoLift must also mean added value and high quality so that our products meet requirements, give the best functionality and stand the test of time. Our products are mostly sold via dealers and subsidiaries in more than 60 countries around the world.

EdmoLift was founded in 1964 by Torbjörn Edmo. The company is located in beautiful Härnösand on the High Coast of Sweden, where we have modern premises for production, development, sales and servicing. Our experienced and skilled staff can provide a rapid response and excellent service.

Our aim is to offer you the best and most ergonomic, cost-effective solution for your lifting and handling needs.

World class from Sweden!