GAS CYLINDER SILICONE HEATING BAND

Installation & Operation



User manual information

Original language of the user manual is English. The user manual is also available in some other languages upon request or at:

Heating-Manuals.com

Product warranty

We warrant that this product will be free from defects in materials and workmanship for a period of one year (up to 1600 hours of use) from the date of shipment. If this product proves defective during its warranty period the manufacturer will either repair the defective product without charge for parts and labor, or provide a replacement in exchange for the defective product.

This warranty shall not apply to any defect, failure or damage caused by improper use or improper or inadequate maintenance and care of the product.

Important safety instructions

- Always inspect the heater for physical damage before use.
- Only operate when securely fastened to the cylinder to be heated.
- · Always monitor the heater while in use.
- Never handle the drum heater while in operation. Always disconnect the heater and let it cool down before handling.
- Disconnect the heater when not in use.
- · Keep away from open flames.
- · Never immerse the heater into liquids.
- Keep the heater away from sharp objects.
- Do not try to repair damaged or faulty heaters.

Warning!!

Read and understand this guide before installing and operating the product. Failure to understand instructions and safety precautions could result in injury, shock, fire, damage to the heating blanket and/or damage to the material being heated. Heating blankets should only be operated by trained professionals.

Page II

Operating the heater

- 1. Fasten to the cylinder to be heated.
- 2. Connect to power.
- 3. Monitor while powered on.
- 4. Disconnect when done using the gas cylinder.
- 5. Store rolled, not folded until next use.

Technical information

- · Material: Silicone.
- Voltage: 230VPower: 500W
- · Electrical protection class II
- Thermostat: Bi-metal thermostat 40°C (104°F).
- Safety: Resetable fuse 55°C (122°F).
- Dimensions: 890x120mm
- Cylinder type: Standard 22kg and 33kg gas cylinders.
- Cylinder diameter (Ø): 299-312mm
- Flexible spring fastening system.
- IP64

Page III

-SILICONE GAS CYLINDER HEATERS -
INSTALLATION & OPERATION